

**HOW TO USE BOSTON VALVE**

1. Double valve cap (valve lets air in; not out).
 2. Quick deflation cap.
 3. Unscrew Double Valve cap.
 4. Insert output end of air pump into valve and fill. Do not over inflate or use high pressure compressor.
 5. To deflate: Unscrew quick-deflation cap.
- CAUTION:** Double-Valve does not operate when this cap is off. Do not unscrew this cap while boat or inflatable is in water.

ANWENDUNG DES BOSTON-VENTILS

1. Doppelventil-Kappe (Ventil lässt die Luft hinein, aber nicht hinaus).
 2. Kappe für schnelles Luftablassen.
 3. Schrauben Sie die Doppelventil-Kappe ab.
 4. Stecken Sie das Auslass-Ende der Luftpumpe in das Ventil. Nicht zu fest aufpumpen oder einen Kompressor mit hohem Druck benutzen.
 5. Luft ablassen: Schrauben Sie die Schnellablass-Kappe ab.
- ACHTUNG:** Das Doppel-Ventil funktioniert nicht, wenn diese Kappe abge-schraubt ist. Schrauben Sie diese Kappe niemals ab, so lange das Boot oder der aufblasbare Artikel im Wasser ist.



©2025 Intex Marketing Ltd. - Intex Development Co. Ltd. - Intex Recreation Corp. All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten. Printed in China/Imprimé en Chine/Impreso en China/Gedruckt in China.

®™ Trademarks used in some countries of the world under license from/®™ Marques utilisées dans certains pays sous licence de/Marcas registradas utilizadas en algunos países del mundo bajo licencia de/Warenzeichen verwendet in einigen Ländern der Welt in Lizenz von/Intex Marketing Ltd. to/a/a/an Intex Development Co. Ltd., Hong Kong & Intex Recreation Corp., P.O. Box 1440, Long Beach, CA 90801 • Distributed in the European Union by/Distribué dans l'Union Européenne par/Distribuido en la union Europea por/Vertriebt in der Europäischen Union durch/Intex Trading B.V., Ettenseweg 46, 4706 PB Roosendaal - The Netherlands • Distributed in the UK by Unitex Service (UK) Limited, 124 City Road, London, England, EC1V 2NX, UK.
www.intexcorp.com

INTEX®