



INTEX® OWNER'S MANUAL

English

46
10

QuickFill™ Tiny USB Pump

Model AP647 3.7V 20W Rechargeable Battery

READ AND FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT



WARNING

- Adult use only.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not drop unit into water or expose unit to rain or water.
- Do not expose the unit to direct sunlight or store it in a hot, enclosed space, as this may cause damage to the battery.
- Do not operate for more than 8 minutes at a time. Let it cool for at least 10 minutes.
- Unplug unit when not in use.
- Do not insert objects into the inflation or deflation connector. Do not obstruct vent holes or open source.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

FOLLOW THESE RULES AND ALL INSTRUCTIONS TO AVOID PROPERTY DAMAGE, ELECTRIC SHOCK, BURNS OR OTHER INJURY.



CAUTION

- To reduce the risk of electric shock, do not expose to rain. Store indoors.

GENERAL


- The product requires an external power adapter (not included) to charge the battery.
- Make sure the output of the external power adapter, such as USB Wall Charger, Portable USB Charger, 12V Car Charger or USB Port is rated 5V / 1A or more for optimum operation.
- It is recommended that the first charge to be 3.5 hours using a USB wall charger rated 5V / 1A or more.
- Maximum air flow: 200-230 (L/Min) / 7-8 (CFM) when is fully charged.

READ AND SAVE THESE INSTRUCTIONS

- The pump is suitable for inflating items with an overall air volume not exceeding 1.3 m³ / 46 ft³, such as inflatable beach balls, swim rings, tubes, ride-on aquatic toys, kids floats, baby pools, single or double users air mats or lounges, single height queen size air bed or camping mats.
- The batteries are permanently sealed in the pump and cannot be removed or replaced. As the pump weakens from use, recharge the batteries. Do not wait until they are fully discharged.
- Do not dispose of air pump and its batteries in fire. Check your local regulations for proper disposal instructions.
- Keep away from heat or direct sunlight.
- No specific air pump maintenance is required. Air pump has no user serviceable parts.

PARTS DESCRIPTION:

1. DEFLATION CONNECTOR
2. INFLATION CONNECTOR
3. NOZZLES
4. USB CABLE
5. SWITCH
6. USB (TYPE C) SOCKET
7. LED LIGHT
8. HOOK



NOTE: Drawings for illustration purpose only. May not reflect actual product. Not to scale.


CHARGE/RECHARGE INSTRUCTIONS

1. Plug the small end of the USB cable into the USB socket. See Fig (1).
2. Connect the other end of the USB cable to one of the following external power adapters (not included):
 - USB Wall Charger rated 5V $\overline{\text{---}}$ / 1A or more. See Fig (2).
 - Portable USB Charger rated 5V $\overline{\text{---}}$ / 1A or more. See Fig (3).
 - 12V Car Charger rated 5V $\overline{\text{---}}$ / 1A or more. See Fig (4).
 - USB Port rated 5V $\overline{\text{---}}$ / 1A or more. See Fig (5).

NOTE: The indicator light turns red during charging mode and green when it is fully charged. Charging time no more than 3.5 hours. The pump or the light cannot be turned on during charging. Remove the USB cable after charging.




FIG (1)



USB Wall Charger

FIG (2)



Portable USB Charger

FIG (3)



12V Car Charger

FIG (4)



5V/1A USB Port

FIG (5)

OPERATING INSTRUCTIONS

The product only operates with the internal batteries charged. Ensure the USB cable is disconnected from the product.

1. Attach a suitable nozzle to the inflation or deflation connector if necessary and hold pump against inflation valve on item to be inflated or deflated. In some items, the "inflation/deflation connector" may fit directly into the inflation valve without the nozzle. See Fig (6).

READ AND SAVE THESE INSTRUCTIONS

2. Press the switch (5) once to start inflating or deflating, press the switch again to turn it off. Press and hold the switch to turn on the light, press once more to turn off the light. See Fig (7).

NOTE: The pump and the light cannot be turned on at the same time.

46
IO

INFLATION



FIG (6)

DEFLATION



FIG (7)

LIGHT



STORAGE INSTRUCTIONS

Make sure the USB cable is free of twist, kink and knot. Fold the USB cable loosely, and return pump, USB cable and nozzles to package when not in use.

To protect and extend the life of the battery, make sure the battery is charged before long term storage, and charge the battery every 3 months thereafter.

TROUBLESHOOTING GUIDE

PROBLEM	CAUSE	SOLUTION
Air pump does not work	<ul style="list-style-type: none"> The pump is charging. Pump running continuously for 8 minutes, motor protection system activated. The battery power is too low. Pump is in power-saving mode. 	<ul style="list-style-type: none"> Switch off and disconnect the USB cable from the pump. Let the pump rest for 10 minutes before restarting. Fully recharge the battery. Press and hold the switch to activate it. The LED light will light up, indicating that it is ready for use.
Item not fully inflated after 6-7 minutes of inflation	<ul style="list-style-type: none"> Item to be inflated is too big. Item inflation air valve not fully pushed open during inflation. The battery power is too low. 	<ul style="list-style-type: none"> Use another air pump with a larger air flow capacity. Use the pointed nozzle to fully push open the air valve during inflation. Fully recharge the battery.
LED light does not work	<ul style="list-style-type: none"> LED light works continuously for 1 hour, power saving mode activated. The battery power is too low. 	<ul style="list-style-type: none"> Press and hold the switch again. Fully recharge the battery.

INTEX®

©2025 Intex Marketing Ltd. - Intex Development Co. Ltd. - Intex Recreation Corp. All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten. Printed in China/Imprimé en Chine/Impreso en China/Gedruckt in China.

®™ Trademarks used in some countries of the world under license from®™ Marques utilisées dans certains pays sous licence de/

Marcas registradas utilizadas en algunos países del mundo bajo licencia de/Warenzeichen verwendet in einigen Ländern der Welt in Lizenz von/Intex Marketing Ltd.

to/à/an Intex Development Co. Ltd., Hong Kong & Intex Recreation Corp., P.O. Box 1440, Long Beach, CA 90801 • Distributed in the European Union by/

Distribué dans l'Union Européenne par/Distribuido en la unión Europea por/Vertrieb in der Europäischen Union durch/Intex Trading B.V., Ettenesseweg 46, 4706 PB

Roosendaal - The Netherlands • Distributed in the UK by Unifex Service (UK) Limited, 124 City Road, London, England, EC1V 2NX, UK. www.intexcorp.com

READ AND SAVE THESE INSTRUCTIONS